



Production Run Sampling - Transdermal Patches



Based on total weight of the entire production run, randomly select the lesser of 1% of the weight or 25 whole units (with a unit being one item), whichever is the lesser amount, rounded up to the nearest unit. The Department has determined that at least 3 units is the minimum required for full testing, regardless of production run size.

Production run sample = 3 units

Production run sample = 4 - 25 units

